


## ICP-W-7010G-2C 系列控制器说明

Made By Shuangyi


## 修订记录:

Rev	Data	Author	Description
1.0	210106	Shuangyi	ICP-W-7010G-2C 系列控制器说明 1、U 盘启动设置选项 2、驱动安装顺序 3、上电自启动设定


## 一、使用 U 盘启动



通过按键“F7”自己设置启动顺序【F7 按键为启动顺序菜单选择】。












选择从 U 盘启动




进入 PE 系统，方便我们后续的操作系统安装。

## 二、驱动程序安装方式

	(USB Patch) for XP	2018-08-11 10:33	文件夹
	Audio	2018-08-11 10:33	文件夹
	Chipset	2018-08-11 10:33	文件夹
	dotnet	2018-08-11 10:33	文件夹
	iAMT 9.0	2018-08-11 10:33	文件夹
	LAN	2018-08-11 10:33	文件夹
	RST	2018-08-11 10:33	文件夹
	USB3.0	2018-08-11 10:33	文件夹
	VGA	2018-08-11 10:33	文件夹

### 驱动程序文件夹

一般安装驱动程序的顺序如下所示：



安装驱动程序的顺序一般如上图所示。

### 三、上电自启动设定

上电自启动设定

开机启动按“DEL”按键可进入 BIOS





Fig.1 "Chipset"标识框

"PCH-IO Configuration"进入此选项中设置，来电自动启动电脑选项：



来电自启动选项

"选中 System State After Power Failure "选项，设置为“Power On”，设置此选项的目的为电源开启后，电脑自动启动。